



Nothing else measures up!

Follow us!

York Survey Supply Centre

@York_Survey

(i) @York_Survey

Prospect House George Cayley Drive Clifton Moor York England YO30 4XE

Tel: +44 (0) 1904 692723 Fax: +44 (0) 1904 690385

E-Mail: sales@yorksurvey.co.uk






Winkeltronic Easy



Operating Instructions

Ref:.. \operat98\instructions 19\26303.qxp 07-01-19

Winkeltronic Easy



a: Control buttons

ON On/off button; reset button when on Hold


HOLD Keep measurement in display

b: Display

Angle in degrees, with sign Upper left: Symbol for low battery

Lower right: Symbol for activated HOLD key

c: Battery compartment (rear): Install batteries in proper position!



- a: Vertical bubble level: Measures angle from vertical.
- b: Horizontal bubble level: Measures angle from horizontal.
- c: Buttons
- d: Display
- e: Battery compartment: To open, push cover in direction of arrow.



WARNING

Danger of pinching hand and fingers



WARNING

Do not touch any live parts. Housing conducts electricity



NOTE

To measure absolute angles, first close instrument all the way and then turn on.

Special Functions



A - To measure **absolute angle**, turn on in folded position.




 \boldsymbol{B} - To measure $\underline{\textbf{relative}}$ angle, turn on in any position.



C - To **keep measurement**, press HOLD button. Measurement in display blinks. To terminate Hold function, press ON.



D - To measure **opposite angle**: Press HOLD and ON at the same time. Degree symbol [o] blinks.



E - To turn on for **continuous measurement**: Press ON for more than 5 sec. "ON" appears briefly in display.

Contact surfaces must be clean.

Dirt can cause measurement errors.

Inspect Winkeltronic Easy regularly for damage and check function.

Check horizontal and vertical levels (Fig. 2, b) regularly by turning over.

If battery symbol appears (Fig. 1, b), batteries (Fig. 1, c) must be replaced.

Measurement range: 200° Display graduations: 0.1° Accuracy: ±0.2°

Power supply: 2 batteries (1.5v - type LR6 (AA))

Operating time: approx. 200h
Automatic switch-off: after 5min
Operating temperature: 0°C to +40°C
Storage temperature: -20°C to +70°C

Remove dirt with a soft, moist cloth.

Do not use any strong solvents.

Winkeltronic Easy does not require calibration. Instrument is ready for use after insertion of batteries.

Protect against moisture and humidity.

Ref...\operat98\instructions 19\26303.qxp 07-01-19