

Crack Detection Pocket Microscope

Operating Instructions


BEFORE USE

Centralize Lamp Beam

In order to illuminate the field of view loosen the knurled ring slightly and twist LED unit until the beam of light is centralised, tighten ring.

Microscope Focusing

The microscope is focused by turning the black knob on the side of the instrument. The eyepiece scale can be rotated to align with the direction of the crack.



NOTE

Please ensure when changing the Battery that it is leak proof type i.e. Duracell.

TROUBLESHOOTING

If the microscope fails to illuminate please make the following checks!

- 1. Battery is in good condition.
- 2. Battery + is next to LED
- 3. Knurled ring is tightened.
- 4. Battery contacts are clean.