YORK
Survey Supply

Nothing else measures up!

Follow us!

York Survey Supply Centre

@York_Survey

@York_Survey

Prospect House
George Cayley Drive
Clifton Moor
York
England
YO30 4XE

Tel: +44 (0) 1904 692723
Fax: +44 (0) 1904 690385

E-Mail: sales@yorksurvey.co.uk

www. **YorkSurvey** .co.uk

...for secure online ordering of all our products!

YORK
Survey Supply

Multi-Function Thermometer

Code: 32076

Operating Instructions

Multi-Function Thermometer

Operating Instructions

Instrument Operation
• Open the battery cover by gently pulling the foot stand to unravel the lead and insert the battery.
• The instrument is switched on by pressing the Power button located on the front of the instrument.
• Remove the protective cover from the probe.
• Insert the probe into the substance being measured.
• The instrument reading may take a few seconds to stabilise, depending on the nature of the measurement.

Hold
• Press the Hold button to capture the temperature reading.
• The 'Hold' icon will flash in the display.
• Press the Hold button again to resume taking the temperature.

MAX/MIN
• Press the MAX/MIN button to display the maximum reading (MAX symbol displayed).
• Press the MAX/MIN button again to display the minimum reading (MIN symbol displayed).
• Press MAX/MIN button again to return to normal readings.
• Hold MAX/MIN for three seconds to reset minimum and maximum temperature memory.
• Please note: Max/Min readings are not saved so switching the thermometer off will clear the max/min readings.

°C/°F
• Press and hold the °C/°F button on the front of the instrument to switch between Centigrade and Fahrenheit.

Audible Alarm
• Press the Set button and the 'HI' value will flash in the display.
• Press the up or down arrows to set the desired 'HI' alarm limit.
• Press the Set button again and the 'LO' value will flash in the display.
• Press the up or down arrows to set the desired 'LO' alarm limit.
• Press the Set button again to set the alarm.
• The audible alarm will sound when the temperature setting has been exceeded.
• Press any button to stop the alarm sounding, the 'HI' or 'LO' symbol will continue to flash until the temperature is within the set limit.
• To disable (turn off) the alarm/s, press the Set button and the 'HI' alarm digits wil flash. Press the Power button once and the display will show 'OFF', repeat for low alarm.

Calibration Function
• Press and hold the Power button until 'CAL' is shown in the display.
• Using the arrow buttons, you can enter an offset temperature by as much as ±2.2°C/°F to compensate for any errors.
• Press the Power button to return to the temperature display.
• If no buttons are pressed the screen will default to the temperature display after a short period of time.

Battery Replacement
• Replace the battery when the display dims, using a AAA or 1.5V equivalent. The battery is located under the battery cover at the rear of the instrument, to change the battery lift the footstand and pull gently.

EMC/RFI
• Instrument performance may be affected if operated within a high frequency radio field, such as near a mobile phone, or if subjected to an electrostatic shock.